

## Front Camber Cam Nut Kit Installation Instructions

1. Inspect vehicle for loose or worn parts and abnormal tire wear patterns.
2. Check alignment to determine amount of caster change needed.
3. Raise and support the front of the vehicle by the frame.
4. Loosen the lower control arm nut (see figure 1)
5. Install cam bolt kit and nut. Snug, but do not tighten at this time. (See figure 2)
6. Watching your alignment readings, adjust caster to the manufacturer's specifications by turning cam nut until the needed adjustment is achieved.
7. While holding cam nut in place, torque bolt to manufacturer's specifications.
8. Repeat procedures for the other side of the vehicle.
9. Proceed with the alignment and road test vehicle.



Figure 1



Figure 2