

Camber/Toe Kit

Installation Instructions

1. Perform pre-alignment checks in a normal manner.
2. Install alignment equipment; record readings and determine amount of camber/caster change needed.
3. Raise rear of vehicle by frame and support in a safe manner.
4. Remove the OE Toe/Camber bolt.
5. Install new Toe/Camber bolt (pump with grease after installed if applicable).
6. Lower vehicle and adjust Toe/Camber using newly installed bolts. When all adjustments are made tighten all bolts to manufacture's specifications
7. Proceed with alignment and road test vehicle.

95-306-1016

Camber/Toe Kit

Installation Instructions

1. Perform pre-alignment checks in a normal manner.
2. Install alignment equipment; record readings and determine amount of camber/caster change needed.
3. Raise rear of vehicle by frame and support in a safe manner.
4. Remove the OE Toe/Camber bolt.
5. Install new Toe/Camber bolt (pump with grease after installed if applicable).
6. Lower vehicle and adjust Toe/Camber using newly installed bolts. When all adjustments are made tighten all bolts to manufacture's specifications
7. Proceed with alignment and road test vehicle.

95-306-1016

Camber/Toe Kit

Installation Instructions

1. Perform pre-alignment checks in a normal manner.
2. Install alignment equipment; record readings and determine amount of camber/caster change needed.
3. Raise rear of vehicle by frame and support in a safe manner.
4. Remove the OE Toe/Camber bolt.
5. Install new Toe/Camber bolt (pump with grease after installed if applicable).
6. Lower vehicle and adjust Toe/Camber using newly installed bolts. When all adjustments are made tighten all bolts to manufacture's specifications
7. Proceed with alignment and road test vehicle.

95-306-1016