

# CHEVY CRUZE REAR CAMBER/TOE SHIM PACK

1. Perform pre inspection, checking for loose or worn parts.
2. Perform complete alignment check to determine the alignment need.
3. Raise the rear the vehicle and support securely.
4. Remove tire and wheel assembly.
5. Loosen the four wheel hub bolts.
6. Pick between the four options of camber/toe shims to achieve proper alignment.
7. Install shim(s) behind the backing plate and evenly torque hub bolts to manufacturer's specification.
8. Reinstall tire assembly and finish alignment.

