

REAR TOE ADJUSTING TOOL BMW 3 SERIES

Installation Instructions:

1. With weight on vehicle and alignment equipment attached, loosen the three (3) frontrailing arm bolts slightly. (See Figure No.1)
2. Place toe adjusting tool between tabs (as shown in figure no.1) and rotate to adjust to proper toe setting.
3. Tighten trailing arm bolts to factory specifications

Note: On some models there may be only one (1) tab provided for the toe adjusting tool to rotate against while making adjustment.

