

Adjusting Sleeve Instruction

1. Remove OE round toe adjusting sleeve.
2. Install new hex shaped adjusting sleeve.