


Point arrow on bottom of
ball joint to correct number
as per chart



TOWARD
WHEEL